


Required components for installation:

- Ethernet cable
- Network with DHCP capable router
- Browser (PC / Mac) or trivum App
- RCA connectors for Line In and/or Line Out
- Speakers with 4 or 8 Ohms impedance

Mounting within a 19" server rack

To mount the device in your cabinet you need to use the special rackmount kit that comes with the device. The brackets can be mounted both from the **back** or from the **front**.

First you need to remove the screws that are currently screwed in, then mount the brackets with **3**x screws that come with the kit (longer screws can damage the electronics!). See example below:



smart multiroom

SC344m AN: 201015

Quick Installation Guide



Technical Data

Zones Source	4 Zone Expandable to up to 64 zones 4x Streaming Clients 4x DAB+/FM Tuner 4x Analog Line Input
Streaming	up to 192kHz 24Bit
Radio	DAB+/FM
External Sources	4x Stereo RCA
Music Formats	MP3, AAC, FLAC, M4A, WMA, ALAC
Connections	1x Network (RJ45 Socket) 1x USB (for service) 4x Speaker Stereo (4-Pin connector) 4x Analog Line Input 4x Analog Line Output 1x DAB+/FM antenna (F socket) 2x USB-C trivum AudioBus Input (SDAT/MDAT) 4x USB-C trivum AudioBus Output (MDAT) 8x Trigger Input/Output (10-pin beam connector) 1x Power (cloverleaf socket)
Amplifier	Class D, 8x 30W @ 4 Ohm
Display	1x OLED display with 128x64 pixels for displaying the IP address
Power Supply	AC 100V-240V (max. 200 watts) Idle power consumption (without active zone): 5 watts
Casing	Black lacquered steel sheet, 435 mm x 65 mm x 254 mm (WxHxD)
Weight (netto)	3,6 kg

1. Connection

1 Connect cables to Line-In, Line-Out or audio speakers, ethernet network and power supply.

2. Configuration

The trivum SC344m can be configured via web browser. If you use a DHCP connection, then the IP Address will be automatically displayed on the device's display.

Enter *"DISPLAYED_IP_ADRESS/setup"* in your web browser, to open Music Center Setup.

We also recommend you to use the trivum Apps or trivum ServerAdmin Tool. The trivum Apps or ServerAdmin Tool will scan and list all trivum devices and their IP addresses in your network.

Using trivum App (iOS or Android)

2.1 Please scan QR Code to download the trivum iOS App or Android App. You can also visit -> https://trivum.de/apps





2.2 Start the App and tap on the button "Select trivum system".



Then all trivum devices in your network, their IP addresses and serial numbers will be listed..



Using trivum ServerAdminTool (Windows)

2.3 Please download and install the ServerAdmin Tool. -> https://trivum.de/admin-tool

2.4 Start the ServerAdmin Tool.

2.5 Double-click on the device (SC344m) to open the Music Center WebConfig (main config site).

i Note: If you are not sure about the assignment of the listed devices, you can compare the serial number in the list with the serial number on your device.

2.6 If you need static IP instead of DHCP: click "*Network*".**2.7** Select "*Use static IP address*".

2.8 Enter your IP settings and Restart to apply changes.

3. Adding a network share

The trivum SC344m can play audio files which are stored on network shares. If you want to use a shared directory, make sure that it supports the media sharing service Samba service (smb). To add a network share (e.g. NAS):

3.1 Open the Music Center WebConfig.
3.2 Click: "Music on NAS -> Setup music library -> Add network share".

3.3 Set the network path and user/password if required.
3.4 Click "Save as new share".
3.5 Click "Refresh" your music index now.

4. Adding your Online streaming service account

4.1 Open the Music Center WebConfig.
4.2 Click "Streaming".
4.3 Click "Add Service".
4.4 Select your favorite service and enter your user account.
4.5 Click Create the streaming service given account.

i Note: trivum supports only paid accounts.

📍 Tip: The SC344m is AirPlay ready, so it's easy to stream every kind of music to the specific zone (with Apple devices).

Backup your configuration

Once you have completed the setup, we recommend you to make a backup of your configuration:

- Open the Music Center WebConfig.
- Click "Backup/Restore -> Export/import configuration".
- Follow the instructions.

For easy operation of your SC344m, we recommend our trivum TouchPad.

How to use a trivum TouchPad?

- Make sure your TouchPad is running software v2.35 or later.
- Wait a few seconds until the TouchPad has booted.
- On the starting screen press "Pair TouchPad with Audio System".
- Press "Select..." and select your preferred trivum MusicCenter from the pop-up menu.

How to use KNX?

- The KNX programming of SC344m is done via the web browser. No need for extra KNX software.
 - Open the Music Center WebConfig.
 - Click "KNX->Setup KNX communication" and enable "use KNX / IP".
 - Follow the instructions.

You find further informations for KNX on:

https://trivum.de/knx-setup

Further documentation and troubleshooting

To find helpful log files in support cases:

- Open the Music Center WebConfig.
- Click "Logs & Warnings".

Please visit also our website for the latest documentation, videos and information:

https://www.trivum.com

https://service.trivum.com

If support is needed Please contact your local trivum dealer or write to:

service@trivum.com

Download links:

trivum ServerAdmin Tool (Windows): https://trivum.de/admin-tool

trivum Apps (iOS, Android, Web): https://trivum.de/apps

